




170-C0A-11 Air Cleaner



Ref.	Part Number	Description
30	951-10806	Air Cleaner Housing
31	712-04213	Nut
32	710-05102	Self-Tapping Bolt M4.2x16
34	951-12135	Silencer Plate
36	951-10794	Air Cleaner Filter Assembly
37	951-12136	Air Cleaner Cover


170-C0A-11 Carburetor



Ref.	Part Number	Description
24	710-05101	Stud M6×110
25	951-11567	Carburetor Insulator Gasket
26	951-11568	Carburetor Insulator
27	951-11569A	Carburetor Gasket
28	951-12124	Carburetor Assembly
29	951-11571	Carburetor Gasket Plate
a	951-11177	Control Lever,Choke
b		Choke Shaft
c		Choke Plate
d		Throttle Shaft
e		Throttle Plate
f		Screw M3×5
g		Lock Washer
h		Idle Jet Assembly
i		Gasket, Throttle Plate
j		Idle Speed Adjusting Screw

Ref.	Part Number	Description
k		Mixture Screw
l		Carburetor Body
m		Float Pin
n		Emulsion Tube
o		Needle Valve
p		Main Jet
q		Needle Valve Spring
r		Float
s	951-11589	Fuel Bowl Gasket
t		Fuel Bowl
u	951-11348	Fuel Bowl Gasket
v	710-04945	Fuel Bowl Mounting Bolt
w	951-11349	Fuel Drain Plug Gasket
x	710-04938	Fuel Drain Plug
	951-12119A	Carburetor Kit - Major (Incl.h,l,j,m,n,o,p,q,r,s,u,w)


170-C0A-11 Crankcase



170-C0A-11 Crankcase


Ref.	Part Number	Description
44	951-12111	Piston Ring Set
45	951-11632	Piston Pin Snap Ring
46	951-12007	Piston
47	951-11633	Piston Pin
48	710-04915	Bolt M6x12
49	951-11113	Air Shield
50	951-11573	Connecting Rod Assembly
51	951-11356	Governor Arm Shaft
52	736-04461	Washer, 5.2x1.9
53	951-11574	Governor Seal
54	714-04074	Cotter Pin
55	951-11575	Camshaft Assy.
56	951-11369	Radial Ball Bearing, 6205
57	951-12133	Crankshaft Assembly
58	951-10307	Woodruff Key
59	951-11576	Governor Gear/Shaft Asm
60	715-04092	Dowel Pin, 7x14
61	715-04089	Dowel Pin, 9x14
62	951-11371	Crankcase Cover Gasket
63	951-12125	Cover Comp, Left Crankcase
64	710-04932	Bolt M8x32
65	951-11283	Oil Fill Plug Assembly
66	951-11578	Oil Seal, 25x741.25x6
67	951-12122A	Crankcase (Incl.4,20,25,26,38,40,41, 44-47,50-57,59-64,66-69)
68	951-12514	Oil Drain Plug
69	951-12126	Oil Seal , 25x741.25x6
82	735-04265	Isolator Bushing
83	735-04266	Rubber Isolation Mount
84	735-04267	Isolator Bushing
	952Z170-C0A-11	Complete Engine
	951-12573	Gasket Kit - External (Incl.4,20,25-27,29)
	951-12572	Gasket Kit - Complete (Incl.4,20,25-27,29,38, 52,53,62,66,69)

170-C0A-11 Starter Assembly




Ref.	Part Number	Description
70	951-10792	Ignition Coil Assembly
71	710-04919	Bolt M6x25
72	951-10805	Flywheel
73	951-10909	Fan, Cooling
74	951-10911	Starter Cup
75	712-04209	Nut, Special M14x1.5
76	710-04915	Bolt M6x12
78	951-11583	Blower Housing
79	736-04455	Gasket 6
80	710-04974	Bolt M6x10
81	951-12418	Recoil Starter
113	712-04212	Nut, M6
114	710-04918	Bolt M6x20
115	951-11109	Blower Housing Shield

170-C0A-11 Muffler



Ref.	Part Number	Description
19	710-04911	Muffler Stud M8x36
19	951-12027	Muffler Stud Assembly
20	951-11285	Exhaust Pipe Gasket
21	712-04214	Nut, M8
22	951-12123	Muffler Assembly
23	710-05002	Bolt M5x10
	777123259	Choke Lever Label
	777533612	Engine Oil / Warning Label
	777123174	Throttle Label
	777123026	Electric Start Warning Label
	777122992	Electric Start Label


170-C0A-11 Cylinder Head



170-C0A-11 Cylinder Head

Ref.	Part Number	Description
1	710-04968	Bolt M6x16
2	951-11054A	Valve Cover
3	731-07059	Breather Hose Assembly
3a	726-04101	Hose Clamp
4	951-11565	Valve Cover Gasket
5	951-11892	Rocker Arm Assembly
6	751-11124	Nut,Pivot Locking
7	751-11123	Adjusting Nut ,Valve
8	951-11893	Rocker Arm
9	710-04902	Bolt, Pivot
10	951-11895	Push Rod Guide
11	951-12000	Retainer, In.Valve Spring
12	951-12002	Adjuster, Exh Valve
13	951-12003	Retainer, Ex.Valve Spring
14	951-12004	Valve Spring
15	951-11894	Intake Valve Seal
16	710-04933	Bolt M8x55
17	951-10668A	Cylinder Head Assembly (Incl.4,6-15,17,20,25,26,38,42,43)
18	951-10292	Spark Plug/F6Rtc
38	951-11572	Gasket, Cylinder Head
39	951-10648	Push Rod
40	951-11899	Tappet
41	715-04090	Dowel Pin, 10x16
42	951-10647A	Valve Kit
43	951-10647A	Valve Kit
116	951-11063A	Valve Cover Kit
	952Z170-C0A-11	Complete Engine
	951-12573	Gasket Kit - External (Incl.4,20,25-27,29)
	951-12572	Gasket Kit - Complete (Incl.4,20,25-27,29,38, 52,53,62,66,69)

170-COA-11 Fuel Tank & Mounting



Ref.	Part Number	Description
1	710-04968	Bolt M6×16
85	951-11067	Throttle Control Knob
86	951-12131	Primer Bracket
87	710-04928	Bolt M6×12
88	951-11585	Governor Spring
89	951-10664	Throttle Linkage Spring
90	951-10665	Throttle Linkage
92	951-11106	Governor Arm
93	712-04212	Nut M6
94	710-04908	Governor Arm Bolt
95	951-10650	Fuel Line Kit
96	951-10650	Fuel Hose Clamp
97	710-04918	Bolt M6×20
98	735-04268	Isolator Bushing
99	951-10662	Dipstick Decoration Cover
100	710-04905	Bolt

Ref.	Part Number	Description
101	710-04915	Bolt M6×12
103	951-11381	Oil Fill Tube O-Ring
104	951-11913	Oil Fill Tube
105	951-11904	Dipstick O-Ring
106	951-12482	Dipstick Guage
107	951-10917A	Fuel Cap Assembly
109	951-11933	Fuel Filter
110	951-12132	Fuel Tank
111	750-05314	Rubber Isolation Mount
112	951-10651	Fuel Tank Nipple
	777123259	Choke Lever Label
	777533612	Engine Oil / Warning Label
	777123174	Throttle Label
	777123026	Electric Start Warning Label
	777122992	Electric Start Label

