



1P70C0A-11 Air Cleaner



Ref.	Part Number	Description
4	712-04212	Nut M6X10Mm
100	951-10297	Air Filter Cover Thumb Screw
101	951-10412B	Air Cleaner Housing Assy Comp
102	951-10298	Air Cleaner Kit
104	710-04969	Bolt M6X30


1P70C0A-11 Carburetor



Ref.	Part Number	Description
107	951-11525	Carburetor Gasket Plate
108	951-10929	Carburetor Assembly
109		Choke Shaft
110		Fiber O-Ring
111		Choke Plate
112		Choke Detent Spring
113		Idle Jet Assembly
114		Throttle Shaft
115		Throttle Plate
116		Screw M3X6 Throttle Plate
117		Lock Washer
118		Fiber O-Ring
119		Idle Speed Adjusting Screw
120		Idle Mixture Screw
121		Carburetor Body
122		Float Pin
123		Emulsion Tube

Ref.	Part Number	Description
124		Needle Valve
125		Main Jet
126		Needle Valve Spring
127		Float
128	951-11589	Fuel Bowl O-Ring
129		Fuel Bowl
130	951-11348	Fuel Bowl Gasket
131	710-04945	Fuel Bowl Mounting Bolt
132	951-11349	Fuel Drain Plug Gasket
133	710-04938	Fuel Drain Plug
134	951-12110	Carburetor Gasket
135	951-11255	Carburetor Insulator
136	951-11254	Carburetor Insulator Gasket
137	710-04981	Carb Stud M6X113
	951-12178A	Carburetor Kit - Major (Incl.110,113,118,119, 122-128,130,132)


1P70C0A-11 Crankcase



1P70C0A-11 Crankcase

Ref.	Part Number	Description
24	710-04916	Bolt M6X14
25	951-12104	Engine Brake Cover Plate
26	951-11602	Label Bracket
27	951-11545	Upper Crankshaft Seal
28	951-11612	Breather Cover Plate
29	951-11613	Breather Gasket
30	732-04718	Breather Spring
31	951-11614	Breather Valve
32	951-11762	Mesh Screen
34	951-10931	Ignition Coil Assembly
35	710-04979	Bolt M6X18
36	951-11680	Flexible Clamp
51	951-10622	Ignition Switch
52	951-12169	Fuel Tank / Console Bracket
53	951-11608	Governor Arm Shaft
54	951-11574	Governor Seal
55	714-04074	Governor Shaft Cotter Pin
56	951-11260	Breather Hose Assembly
57	726-04101	Breather Hose Clamp
71	951-12177	Short Block Assembly (Incl.24,27-32,40,53-55,71-74, 79,82,83,91,93-98,107,135,136, 152,155,160,161,163,164,169, 170-173,176)
72	951-11763	Crankcase Cover Gasket
169	951-12111	Piston Ring Set
170	951-11632	Piston Pin Snap Ring
171	951-11633	Piston Pin
172	951-11634	Piston
173	951-11768	Connecting Rod Assembly
176	710-05162	Connecting Rod Bolt
	952Z1P70C0A-11	Complete Engine
	951-11772	Gasket Kit - External (Incl.29,79,95,134,136,152,155)
	951-11770	Gasket Kit - Complete (Incl.27,29,54,72,79,95,98,134, 136,152,155,160)


1P70C0A-11 Crankshaft & Crankcase Cover



Ref.	Part Number	Description
24	710-04916	Bolt M6X14
40	710-04922	Bolt M8X50
73	951-11369	Main Bearing
74	951-12174	Crankshaft Assembly
75	951-10307	Woodruff Key
76	710-04980	Bolt M6X35
78	951-11764	Dipstick Assembly
79	951-11547	Dipstick / Oil Fill Tube O-Ring
80	951-11765	Oil Filler Tube Assembly
81	736-04491	Crankshaft Thrust Washer


Ref.	Part Number	Description
82	951-11625	Governor Gear Mounting Plate
83	951-11626	Governor Gear/Shaft Assembly
93	715-04092	Crankcase Cover Dowel Pin 7x14
94	715-04089	Crankcase Cover Dowel Pin 9x14
95	736-04440	Oil Drain Plug Washer
96	710-04906	Oil Drain Plug
97	951-11794	Crankcase Cover
98	951-11627	Lower Crankshaft Seal
177	951-10370	Oil Drain Plug And Washer Assy

1P70C0A-11 Flywheel & Shroud



Ref.	Part Number	Description
1	710-04744	Self-Tapping Bolt, #12-16 X 1.00"
2		Outer Shroud (See Unit Breakdown)
3	951-11720	Recoil Starter Assembly
4	712-04212	Nut M6X10Mm Starter/Carb/Muff
7	951-11721	Recoil Spring And Pulley Assy
15	710-04976	Shroud Stud Left/Black
16	710-04977	Shroud Stud Front/Unmarked
17	710-04978	Shroud Stud Right/White
18	951-10369	Inner Shroud
19	750-05320	Spacer
20	712-04287	Flywheel Nut M14
21	951-12176	Starter Cup
22	951-10909	Cooling Fan
23	951-10935	Flywheel


1P70C0A-11 Cylinder Head



1P70C0A-11 Cylinder Head

Ref.	Part Number	Description
4	712-04212	Nut M6X10M
24	710-04916	Bolt M6X14
138	951-10413A	Cylinder Head Assembly (Incl.135,136,138,141-150,152,155,160)
139	710-04982	Bolt M8X54 Cylinder Head
140	951-10292	Spark Plug/F6Rtc
141	951-10345	Valve Kit
142	951-11818	Intake Valve Seal
143	951-10345	Valve Kit
144	951-12116	Valve Spring
145	951-12000	Valve Spring Retainer
146	951-11629	Push Rod Guide
147	710-04902	Rocker Arm Stud
148	951-12175	Rocker Arm
149	751-11123	Fulcrum Nut
150	751-11124	Jam Nut
151	951-11606	Rocker Arm Assembly
152	951-11551	Valve Cover Gasket
153	951-11548	Valve Cover
154	710-05094	Muffler Stud M6X95
154	951-10342	Muffler Stud Assemblby
155	951-11739	Muffler Gasket
156	951-10403	Muffler Assembly
157	951-10411	Muffler Shield
158	951-10351	Spark Arrestor
159	710-04983	Spark Arrestor Screw
160	951-11630	Cylinder Head Gasket
161	715-04090	Cylinder Head Dowel Pin 10x16
162	751-10344	Push Rod Kit
163	951-11607	Tappet
164	951-11767	Camshaft Assembly
	952Z1P70C0A-11	Complete Engine
	951-11772	Gasket Kit - External (Incl.29,79,95,134,136,152,155)
	951-11770	Gasket Kit - Complete (Incl.27,29,54,72,79,95,98,134, 136,152,155,160)

1P70COA-11 Fuel Tank & Mounting



Ref.	Part Number	Description
24	710-04916	Bolt M6X14
33	951-11616	Fuel Tank Bottom Bracket
36	951-11680	Flexible Clamp
37	736-04456	Fuel Tank Washer
38	951-10335	Rubber Bushing
39	750-05322	Fuel Tank Bushing
40	710-04922	Bolt M8X50
41	951-10368	Fuel Tank Assembly
42	951-10300	Fuel Cap Assembly
47	951-10358A	Fuel Filter
48	951-11700	Fuel Hose Clamp
49	951-10364	Fuel Line Kit

Ref.	Part Number	Description
50	723-04071	Plastic Support Clamp
59	951-12107	Choke Linkage
60	951-12170	Component Bracket
61	710-04915	Bolt M6X12
62	951-10933	Choke Control
63	951-10387	Governor Spring
64	951-12171	Governor Arm Guard
66	710-04908	Governor Arm Bolt
67	712-04212	Governor Arm Nut M6
68	951-12172	Governor Arm
69	951-11259	Throttle Linkage Rod
70	951-11258	Throttle Linkage Spring

Lined writing area with 21 horizontal lines.