



1P70L0A-11 Air Cleaner



Ref.	Part Number	Description
2	712-04212	Nut M6
76	710-04980	Bolt M6x35
101	951-10297	Air Filter Cover Thumb Screw
102	951-10412B	Air Filter Base
103	951-10298	Air Filter Element,Sponge


1P70LOA-11 Carburetor



Ref.	Part Number	Description
107	951-11525	Carburetor Gasket Plate
108	951-10929	Carburetor Assembly
109		Choke Shaft
110		Fiber O-Ring
111		Choke Plate
112		Choke Return Spring
113		Idle Jet Assembly
114		Throttle Shaft
115		Throttle Plate
116		Lock Washer
117		Screw M3x6
118		Fiber O-Ring
119		Idle Speed Adjusting Screw
120		Idle Mixture Screw
121		Carburetor Body
122		Float Pin
123		Emulsion Tube

Ref.	Part Number	Description
124		Needle Valve
125		Main Jet
126		Needle Valve Spring
127		Float
128	951-11589	Fuel Bowl O-Ring
129		Fuel Bowl
130	951-11348	Fuel Bowl Gasket
131	710-04945	Fuel Bowl Mounting Bolt
132	951-11349	Fuel Drain Plug Gasket
133	710-04938	Fuel Drain Plug
134	951-12110	Carburetor Gasket
135	951-11255	Carburetor Insulator
136	951-11254	Carburetor Insulator Gasket
137	710-04981	Carb Stud M6x113
	951-12178	Carburetor Kit - Major (Incl.110,118,119,122-129,130,132)


1P70L0A-11 Crankcase



1P70L0A-11 Crankcase

Ref.	Part Number	Description	Ref.	Part Number	Description
22	710-04916	Bolt M6x14	67	712-04212	Nut M6
23	951-12104	Air Guide Bracket	68	951-12172	Governor Arm
24	951-11602	Label Bracket	69	951-11259	Throttle Linkage
25	951-11545	Upper Crankshaft Seal	70	951-11258	Throttle Linkage Spring
26	951-11612	Breather Cover Plate	71	951-11992	Short Block Assembly (Incl.22,25-30,53-55,71-74,79,81-83, 93-99,107,135,136,152,155,160, 161,163-165,170-176,176)
27	951-11613	Breather Gasket	72	951-11763	Crankcase Cover Gasket
28	732-04718	Breather Spring	165	951-12111	Piston Ring Set
29	951-11614	Breather Valve	170	951-11632	Piston Pin Snap Ring
30	951-11762	Mesh Screen	171	951-11633	Piston Pin
32	951-10931	Ignition Coil Assembly	172	951-11634	Piston
33	710-04979	Bolt M6x18	173	951-11768	Connecting Rod Assembly
34	951-11680	Flexible Clamp	176	710-05162	Connecting Rod Bolt
53	951-11608	Governor Arm Shaft		952Z1P70L0A-11	Complete Engine
54	951-11574	Governor Seal		951-11772	Gasket Kit - External (Incl.27,79,96,136,146,152,155)
55	714-04074	Cotter Pin		951-12178	Carburetor Kit - Major (Incl.110,118,119,122-129,130,132)
56	951-11260	Breather Hose Assembly		951-11770	Gasket Kit - Complete (Incl.25,27,54,72,79,96,99,134, 136,152,155,160)
57	726-04101	Breather Hose Clamp			
59	951-12107	Choke Linkage			
60	951-12170	Variable Speed Control Brkt			
61	710-04941	Bolt M6x12			
62	951-12187	Choke Control Knob			
63	951-10387	Governor Spring			
64	951-12171	Governor Arm Shield			
66	710-04908	Governor Arm Bolt			


1P70L0A-11 Crankshaft & Crankcase Cover



Ref.	Part Number	Description
22	710-04916	Bolt M6×14
73	951-11369	Main Bearing
74	951-12108	Crankshaft Assembly
75	951-10307	Woodruff Key
76	710-04980	Bolt M6×35
78	951-11764	Dipstick Assembly
79	951-11547	Dipstick / Fill Tube O-Ring
80	951-11765	Oil Fill Tube Asm
81	736-04491	Crankshaft Thrust Washer
82	951-11625	Governor Gear Mounting Plate


Ref.	Part Number	Description
83	951-11626	Governor Gear/Shaft Assembly
93	715-04092	Dowel Pin 7×14
94	715-04096	Dowel Pin 9×14
95	710-04922	Bolt M8×50
96	736-04440	Oil Drain Plug Washer
97	710-04906	Oil Drain Plug
98	951-11794	Crankcase Cover
99	951-11627	Lower Crankshaft Seal
177	951-10370	Oil Drain Plug And Washer Ass'Y

1P70L0A-11 Flywheel & Shroud



Ref.	Part Number	Description
1	951-11720	Recoil Starter Assembly
2	712-04212	Nut M6
5	951-11721	Recoil Spring
13	710-04976	Shroud Stud M6x85-48
14	710-04977	Shroud Stud M6x87-51.5
15	710-04978	Shroud Stud M6x79
16	951-12183	M6 Inner Shroud
17	750-05320	Spacer
18	712-04287	Nut M14x1.5
19	951-12176	Starter Cup
20	951-10934	Cooling Fan
21	951-10935	Flywheel


1P70L0A-11 Cylinder Head



1P70L0A-11 Cylinder Head

Ref.	Part Number	Description
2	712-04212	Nut M6
22	710-04916	Bolt M6x14
138	951-10413A	Cylinder Head Assembly (Incl.135,136,138,141-146, 148-152,155,160)
139	710-04982	Head Bolt M8x54
140	951-10292	Spark Plug/F6Rtc
141	951-10345	Valve Kit
142	951-11818	Intake Valve Seal
143	951-10345	Valve Kit
144	951-12116	Valve Spring
145	951-12000	Valve Spring Retainer
146	951-11629	Push Rod Guide
147	951-11606	Rocker Arm Assembly
148	710-04902	Rocker Arm Stud
149	951-12175	Rocker Arm
150	751-11123	Valve Adjusting
151	751-11124	Pivot Locking Nut
152	951-11551	Valve Cover Gasket
153	951-11548	Valve Cover
154	710-05094	Muffler stud M6x95
154	951-10342	Muffler Stud Assembly
155	951-11739	Muffler Gasket
156	951-10403	Muffler Assembly
157	951-10411	Muffler Shield
158	951-10351	Spark Arrestor
159	710-04983	Spark Arrestor Screw
160	951-11630	Cylinder Head Gasket
161	715-04108	Dowel Pin 10x16
162	751-10344	Push Rod Kit
163	951-11607	Tappet
164	951-11767	Camshaft Assembly
	952Z1P70L0A-11	Complete Engine
	951-11772	Gasket Kit - External (Incl.27,79,96,136,146,152,155)
	951-12178	Carburetor Kit - Major (Incl.110,118,119,122-129,130,132)
	951-11770	Gasket Kit - Complete (Incl.25,27,54,72,79,96,99,134, 136,152,155,160)

1P70L0A-11 Fuel Tank & Mounting



Ref.	Part Number	Description
22	710-04916	Bolt M6x14
31	951-12184	Fuel Tank Bottom Bracket
35	710-04968	Fuel Tank Bolt
36	951-12185	Fuel Tanksupport Bracket
38	951-12186	Control/Tank Bracket
39	951-12289	Ignition Key Switch
41	951-12191	Fuel Tank - Clear White
42	951-12291	Fuel Cap Assembly
46	951-10358A	Fuel Filter
47	951-12290	Fuel Shut Off Valve
48	951-12192	Fuel Shut Off Support Clip
49	951-11731	Fuel Hose Clamp
51	951-12188	Fuel Line Kit
52	723-04071	Plastic Support Clamp