


179 cc 265-JU Engine



179 cc 265-JU Engine

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	710-04968	Bolt	86	951-10805	Flywheel
2	951-11054	Valve Cover	87	951-10909	Cooling Fan
3	731-07059	Breather Hose	88	951-10911	Starter Cup
4	726-04101	Hose Clamp	89	712-04209	Nut
7	751-11124	Pivot Locking Nut	90	951-10647	Valve Kit (incl. intake & exhaust valve)
8	751-11123	Valve Adjusting Nut	92	751-12014	Blower Housing
10	710-04902	Pivot Bolt	93	736-04455	Washer
15	710-04933	Bolt	94	710-04974	Bolt
18	951-10292	Spark Plug	95	751-12015	Recoil Starter
19	751-12010	Muffler Assembly	96	731-05696	Starter Handle
20	710-05276	Stud	98	951-11104	Governor Spring Bracket
21	951-11285	Muffler Gasket	99	751-12016	Governor Shield
22	712-04214	Nut	100	751-12017	Governor Spring
23	710-05002	Bolt	101	951-10664	Throttle Return Spring
24	951-10962	Heater Box Base	102	951-10665	Governor Rod
26	710-04915	Bolt	104	712-04212	Nut
28	710-05101	Stud, M6 x110	105	710-04908	Bolt
29	710-04919	Bolt	113	751-11913	Dipstick Tube
33	951-12011	Carburetor Assembly	115	751-11912	Dipstick
37	712-04213	Nut	119	951-11106	Governor Arm Bracket
44	951-10961	Heater Box	121	951-11903	O-Ring
45	710-05275	Bolt	122	751-11934	O-Ring
47	951-10648	Push Rod Kit (incl. intake & exhaust rod)	125	710-05182	Bolt
49	715-04090	Dowel Pin	126	715-04088	Dowel Pin
57	951-11113	Air Shield	127	951-10645A	Electric Starter
59	951-11356	Governor Arm Shaft	128	710-04979	Bolt
60	736-04461	Washer	129	951-11109	Blower Housing Shield
62	714-04074	Cotter Pin	130	951-10639A	Primer
64	951-11369	Radial Ball Bearing	131	710-04945	Bolt
65	951-10307	Flywheel Key	132	710-04938	Drain Bolt
68	715-04092	Dowel Pin, 7 x 14	—	952Z265-JU	Engine, Complete
69	715-04096	Dowel Pin, 9 x 14	56	951-11283	Oil Fill Plug Assembly
70	951-11371	Crankcase Cover Gasket	73	951-11577	O-Ring
72	710-04932	Cover Bolt	74	—	Oil Fill Plug
75	951-11368	Oil Seal	—	951-11063	Valve Cover Kit (Not Shown)
78	736-04440	Washer	2	951-11054	Valve Cover
80	951-11370	Oil Seal	5	951-11565	Head Cover Gasket
81	751-12013	Ignition Coil	—	751-11913	Oil Fill Tube Assembly
83	751-12012	Fuel Line Kit (incl. clamps & fuel line)	113	751-11913	Dipstick Tube
85	951-10370	Oil Drain Assembly, includes 78, 79	121	951-11903	O-Ring

179 cc 265-JU Engine

Ref. No.	Part No.	Description
33	751-12011	Carburetor Assembly
25	—	Main Jet
27	—	Needle Valve Spring
35	—	Float
36	951-11589	Fuel Bowl Gasket
38	951-11349	Fuel Drain Plug Gasket
39	951-11348	Fuel Bowl Gasket
43	—	Choke Shaft
77	—	Choke Plate
82	—	Throttle Shaft
84	—	Throttle Plate
97	—	Screw, M3x5
109	—	Lock Washer
110	—	Idle Jet Assembly
117	—	Idle Speed Adjusting Screw
118	—	Fuel Bowl
123	751-11906	Hose Clamp
124	751-12019	Primer Hose
130	951-10639A	Primer
131	710-04945	Bolt
132	710-04938	Drain Bolt
133	—	Gasket, Throttle Plate
134	—	Float Pin
135	—	Emulsion Tube
136	—	Needle Valve
—	751-12028	Gasket Kit, Complete (Not Shown)
5	951-11565	Head Cover Gasket
21	951-11285	Muffler Gasket
30	951-11567	Carburetor Insulator Gasket
31	951-11568	Carburetor Insulator Plate
32	751-11569A	Carburetor Gasket
34	951-11571	Carburetor Gasket Plate
46	751-11898	Cylinder Head Gasket
60	736-04461	Washer
61	751-11902	Governor Seal
62	714-04074	Cotter Pin
70	951-11371	Crankcase Cover Gasket
75	951-11368	Oil Seal
78	736-04440	Washer
80	951-11370	Oil Seal

Ref. No.	Part No.	Description
—	951-10722A	Cylinder Head Assembly (Not Shown)
5	951-11565	Head Cover Gasket
6	751-12000	Intake Valve Spring Seat
7	751-11124	Pivot Locking Nut
8	751-11123	Valve Adjusting Nut
9	751-11893	Rocker Arm
10	710-04902	Pivot Bolt
11	751-12002	Exhaust Valve Adjuster
12	751-12003	Exhaust Valve Spring Seat
13	751-12004	Valve Spring
14	751-11894	Intake Valve Seal
16	751-11895	Push Rod Guide Plate
17	—	Cylinder Head — Complete
21	951-11285	Muffler Gasket
30	951-11567	Carburetor Insulator Gasket
31	951-11568	Carburetor Insulator Plate
46	751-11898	Cylinder Head Gasket
90	951-10647	Valve Kit
—	751-12031	Crankcase Kit (Not Shown)
61	751-11902	Governor Seal
64	951-11369	Radial Ball Bearing
70	951-11371	Crankcase Cover Gasket
76	—	Crankcase
80	951-11370	Oil Seal
—	951-11020	Carburetor Kit, Major (Not Shown)
25	—	Main Jet
27	—	Needle Valve Spring
35	—	Float
36	951-11589	Fuel Bowl Gasket
38	951-11349	Fuel Drain Plug Gasket
39	951-11348	Fuel Bowl Gasket
133	—	Gasket, Throttle Plate
134	—	Float Pin
135	—	Emulsion Tube
136	—	Needle Valve
—	751-11912	Dipstick Assembly
115	751-11912	Dipstick
122	751-11934	O-Ring
40	751-12027	Muffler Stud Assembly
20	710-05276	Stud

179 cc 265-JU Engine

Ref. No.	Part No.	Description
—	751-12029	Short Block Assembly (Not Shown)
5	951-11565	Head Cover Gasket
21	951-11285	Muffler Gasket
30	951-11567	Carburetor Insulator Gasket
31	951-11568	Carburetor Insulator Plate
46	751-11898	Cylinder Head Gasket
48	751-11899	Tappet
49	715-04090	Dowel Pin
52	951-11553	Piston Ring Set
53	951-11632	Piston Pin Snap Ring
54	751-11900	Piston
55	751-11901	Piston Pin
58	951-11573	Connecting Rod Assembly
59	951-11356	Governor Arm Shaft
60	736-04461	Washer
61	751-11902	Governor Seal
62	714-04074	Cotter Pin
63	951-11575	Camshaft Assembly
64	951-11369	Radial Ball Bearing
65	951-10307	Flywheel Key
66	—	Crankshaft Assembly
67	951-11576	Governor Gear/Shaft Assembly
68	715-04092	Dowel Pin, 7 x 14
69	715-04096	Dowel Pin, 9 x 14
70	951-11371	Crankcase Cover Gasket
71	—	Cover Complete, Left Crankcase
72	710-04932	Cover Bolt
73	951-11577	O-Ring
74	—	Oil Fill Plug
75	951-11368	Oil Seal
76	—	Crankcase
78	736-04440	Washer
79	710-04906	Oil Drain Plug Washer
80	951-11370	Oil Seal

Ref. No.	Part No.	Description
—	751-12026	Gasket Kit, External (Not Shown)
5	951-11565	Head Cover Gasket
21	951-11285	Muffler Gasket
30	951-11567	Carburetor Insulator Gasket
31	951-11568	Carburetor Insulator Plate
32	751-11569A	Carburetor Gasket
34	951-11571	Carburetor Gasket Plate
78	736-04440	Washer
—	951-11246	Crankcase Cover Kit (Not Shown)
64	951-11369	Radial Ball Bearing
70	951-11371	Crankcase Cover Gasket
71	—	Case Cover
72	710-04932	Cover Bolt
73	—	O-Ring
74	—	Oil Fill Plug
75	951-11368	Oil Seal
—	751-12030	Crankshaft Kit (Not Shown)
64	951-11369	Radial Ball Bearing
65	951-10307	Flywheel Key
66	—	Crankshaft Assembly
75	951-11368	Oil Seal
80	951-11370	Oil Seal