


Engine Model 5P65M0B



NOTE: Illustrated parts without a numeric call-out are not servicable components.

Engine Model 5P65MOB

Ref No.	Part Number	Description
1	710-04744	Self-Tap Bolt, Hilo #12-16 x 1.00"
3	951-11720	Recoil Starter Assembly
6	712-04212	Nut M6 X 10 Mm
7	951-11721	Recoil Spring and Pulley Assembly
15	751-11722	Starter/Shroud Stud Black/Ye Zinc
16	951-11723	Starter/Shroud Stud Front/Ye Zinc
17	951-11724	Starter/Shroud Stud White/Ye Zinc
18	951-10875	Inner Shroud
19	750-05320	Engine Shroud Spacer
20	712-04221	Flywheel Nut M14
21	951-11043	Flywheel
22	951-10320A	Brake Assembly
37	750-05384	Brake Spacer
38	710-04980	Bolt M6x35
39	710-04969	Bolt M6x30
40	951-10367	Ignition Coil Assembly
41	750-05383	Ignition Coil Spacer
42	710-04916	Bolt M6x14
43	951-11612	Breather Cover Plate
44	951-11613	Breather Gasket
45	951-11596	Upper Crankshaft Seal
46	951-11730	Mesh Screen
47	732-04718	Breather Valve Spring
48	951-11614	Breather Valve
49	951-11542	Fuel Tank Bottom Bracket
50	736-04456	Fuel Tank Washer
51	951-10335	Rubber Bushing
52	951-11748	Tank/Label Bracket
53	750-05322	Fuel Tank Bushing
54	710-04922	Tank Bolt M8x50
55	951-10300	Fuel Cap Assembly
59	951-10337	Fuel Tank Assembly
60	951-10358	Fuel Filter
61	951-11731	Fuel Hose Clamp
63	723-04071	Plastic Support Clamp
64	951-11520	Breather Hose Assembly
67	951-11608	Governor Arm Shaft
68	951-11574	Governor Seal
69	714-04074	Governor Cotter Pin
70	951-11521	Throttle Linkage Rod

Ref No.	Part Number	Description
71	951-11522	Throttle Linkage Spring
73	951-11523	Governor Arm
74	712-04212	Governor Arm Nut M6
75	710-04908	Governor Arm Bolt
76	951-10293	Governor Spring
77	710-04915	Bolt M6x12
78	951-11544	Throttle / Governor Bracket
79	951-11524	Choke Linkage Rod
80	951-11792	Air Vane Bracket
81	951-11529	Air Vane
83	951-11732	Crankcase Cover Gasket
84	951-11369	Main Bearing
85	951-11591	Crankshaft Assembly
86	951-10307	Woodruff Key
87	951-11733	Oil Return Seal
88	736-04491	Crankshaft Thrust Washer
91	951-11547	Dipstick and Oil Fill Tube O-Ring
93	951-11609	Governor Gear Mounting Plate
94	951-11549	Governor Gear/Shaft Assembly
104	715-04092	Crankcase Cover Dowel 7x14
105	710-04920	Coil/Sump Bolt M6x28
106	951-11793	Crankcase Cover
107	715-04096	Dowel Pin 9x14
108	736-04440	Oil Drain Plug Washer
109	710-04906	Oil Drain Plug
110	951-11545	Lower Crankshaft Seal
112	951-10297	Air Filter Cover Thumb Screw
118	951-11257	Carburetor Gasket Plate
119	951-10873	Carburetor Assembly
136	951-11589	Fuel Bowl O-Ring
142	951-11348	Fuel Bowl Gasket
143	710-04945	Fuel Bowl Mounting Bolt
144	710-04903	Fuel Drain Plug
145	951-11349	Fuel Drain Plug Gasket
146	951-11737	Carburetor Gasket
147	951-11738	Carburetor Insulator
148	951-11528	Carburetor Insulator Gasket
149	710-05093	Carb Stud M6x92
150	710-04982	Head Bolt M8x54
152	951-10292	Spark Plug/F6rtc

Engine Model 5P65M0B

Ref No.	Part Number	Description
154	951-11818	Intake Valve Seal
158	951-11687	Push Rod Guide
159	951-11606	Rocker Arm Assembly
160	710-04902	Rocker Arm Stud
162	751-11123	Valve Adjustment Nut
163	751-11124	Pivot Locking Nut
164	951-11551	Valve Cover Gasket
165	951-11548	Valve Cover
166	710-05094	Muffler Stud M6x95
167	951-11739	Muffler Gasket
168	951-10295	Muffler Assembly
169	951-11791	Muffler Shield
170	951-10351	Spark Arrestor
171	710-04983	Spark Arrestor Screw
172	951-11555	Cylinder Head Gasket
173	715-04090	Cylinder Head Dowel 10x16
175	951-11607	Tappet
176	951-11741	Camshaft Assembly
177	951-11688	Piston Ring Set
182	951-11603	Piston Pin Snap Ring
183	951-11604	Piston Pin
184	951-11605	Piston
185	951-11744	Connecting Rod Assembly
188	710-05162	Connecting Rod Bolt
—	951-11765	Oil Filler Tube Assembly
91	951-11547	Dipstick and Oil Fill Tube O-Ring
92	—	Tube
—	951-11795	Dipstick Assembly
90	—	Dipstick
91	951-11547	Dipstick and Oil Fill Tube O-Ring
—	951-10298	Air Cleaner Kit
114	—	Foam Filter Element
115	—	Paper Filter Element
—	951-10300	Fuel Cap Assembly
56	—	Fuel Cap
57	—	Foam Insert
58	—	Vent Gasket
—	951-10876	Air Cleaner Housing Ass'y Comp
113	—	Outer Air Cleaner Cover
117	—	Inner Air Cleaner Housing

Ref No.	Part Number	Description
—	951-10874	Carburetor Kit - Major
124	—	Fiber O-Ring
130	—	Fiber O-Ring
131	—	Idle Speed Adjusting Screw
134	—	Main Nozzle / Emulsion Tube
135	—	Main Jet
136	—	Fuel Bowl O-Ring
137	—	Needle Valve
138	—	Needle Valve Spring
139	—	Float
140	—	Float Pin
142	951-11348	Fuel Bowl Gasket
145	951-11349	Fuel Drain Plug Gasket
—	951-10342	Muffler Stud Assembly
166	710-05094	Muffler Stud
—	951-11721	Recoil Spring and Pulley Assembly
7	951-11721	Recoil Spring and Pulley Assembly
8	—	Starter Pulley
—	951-10363	Fuel Line Kit
60	951-10358	Fuel Filter
61	951-11731	Fuel Hose Clamp
62	—	Fuel Hose
—	951-10370	Oil Drain Plug and Washer Ass'y
108	736-04440	Oil Drain Plug Washer
109	710-04906	Oil Drain Plug
—	951-11787	Gasket Kit - Complete
44	951-11613	Breather Gasket
45	951-11596	Upper Crankshaft Seal
68	951-11574	Governor Seal
83	951-11732	Crankcase Cover Gasket
91	951-11547	Dipstick and Oil Fill Tube O-Ring
108	736-04440	Oil Drain Plug Washer
110	951-11545	Lower Crankshaft Seal
146	951-11737	Carburetor Gasket
147	951-11738	Carburetor Insulator
148	951-11528	Carburetor Insulator Gasket
164	951-11551	Valve Cover Gasket
167	951-11739	Muffler Gasket
172	951-11555	Cylinder Head Gasket

Engine Model 5P65MOB

Ref No.	Part Number	Description
—	951-11789	Short Block
42	710-04916	Bolt M6x14
43	951-11612	Breather Cover Plate
44	951-11613	Breather Gasket
45	951-11596	Upper Crankshaft Seal
46	951-11730	Mesh Screen
47	732-04718	Breather Valve Spring
48	951-11614	Breather Valve
67	951-11608	Governor Arm Shaft
68	951-11574	Governor Seal
69	714-04074	Governor Cotter Pin
82	—	Crankcase
83	951-11732	Crankcase Cover Gasket
84	951-11369	Main Bearing
85	951-11591	Crankshaft Assembly
86	951-10307	Woodruff Key
87	951-11733	Oil Return Seal
88	736-04491	Crankshaft Thrust Washer
91	951-11547	Dipstick and Oil Fill Tube O-Ring
93	951-11609	Governor Gear Mounting Plate
94	951-11549	Governor Gear/Shaft Assembly
104	715-04092	Dowel Pin 7x14
105	710-04920	Coil/Sump Bolt M6x28
106	951-11793	Crankcase Cover
107	715-04096	Dowel Pin 9x14
108	736-04440	Oil Drain Plug Washer
109	710-04906	Oil Drain Plug
110	951-11545	Lower Crankshaft Seal
118	951-11257	Carburetor Gasket Plate
147	951-11738	Carburetor Insulator
148	951-11528	Carburetor Insulator Gasket
164	951-11551	Valve Cover Gasket
167	951-11739	Muffler Gasket
172	951-11555	Cylinder Head Gasket
173	715-04090	Cylinder Head Dowel 10x16
175	951-11607	Tappet
176	951-11741	Camshaft Assembly
177	951-11688	Piston Ring Set
182	951-11603	Piston Pin Snap Ring
183	951-11604	Piston Pin

Ref No.	Part Number	Description
184	951-11605	Piston
185	951-11744	Connecting Rod Assembly
188	710-05162	Connecting Rod Bolt
—	951-11746	Cylinder Head Assembly
147	951-11738	Carburetor Insulator
148	951-11528	Carburetor Insulator Gasket
151	—	Cylinder Head
153	—	Intake Valve
154	—	Intake Valve Seal
155	—	Exhaust Valve
156	—	Valve Spring
157	—	Valve Spring Retainer
158	951-11687	Push Rod Guide
160	710-04902	Rocker Arm Stud
161	—	Rocker Arm
162	751-11123	Valve Adjustment Nut
163	751-11124	Pivot Locking Nut
164	951-11551	Valve Cover Gasket
167	951-11739	Muffler Gasket
172	951-11555	Cylinder Head Gasket
—	951-11788	Gasket Kit - External
44	951-11613	Breather Gasket
91	951-11547	Dipstick and Oil Fill Tube O-Ring
108	736-04440	Oil Drain Plug Washer
146	951-11737	Carburetor Gasket
147	951-11738	Carburetor Insulator
148	951-11528	Carburetor Insulator Gasket
164	951-11551	Valve Cover Gasket
167	951-11739	Muffler Heat Shield Gasket
—	951-10314	Push Rod Kit
174	—	Push Rod
—	951-10313	Valve Kit
153	—	Intake Valve
155	—	Exhaust Valve
—	951-10846A	Cylinder Head Kit
150	710-04982	Head Bolt M8x54
154	—	Intake Valve Seal
164	951-11551	Valve Cover Gasket
172	951-11555	Cylinder Head Gasket